

# **KINDAS Amusement Source**

## **OPERATING INSTRUCTIONS**

### **SUPERMAN**

**DO NOT OPERATE THE KINDAS' JUMP IN WINDY OR UNFAVORABLE WEATHER CONDITIONS. KINDAS' JUMPS CAN TURN OVER BY HIGH WINDS SEVERELY INJURING OCCUPANTS.**

Make sure that the **KINDAS' JUMP** is fully inflated before letting riders inside. Never allow riders on a partially inflated unit. All riders must remove their shoes and empty their pockets of any hard objects that can injure themselves or others while jumping. Eyeglasses and jewelry should also be removed. This includes watches, bracelets, necklaces, etc...

**Riders should all be of the same age group** and should be limit to the maximum numbers of riders shown below. Never allow more riders in the unit than is shown. A competent adult must supervise the unit at all times.

|                  |                      |                      |                       |                    |
|------------------|----------------------|----------------------|-----------------------|--------------------|
| <b>CAPACITY:</b> | <b>UNDER 5 YEARS</b> | <b>6-8 YEARS OLD</b> | <b>9-13 YEARS OLD</b> | <b>OLDER TEENS</b> |
| <b>17 X 17</b>   | <b>(10)</b>          | <b>(8)</b>           | <b>(5)</b>            | <b>(2)</b>         |

In the event of severe weather, remove all riders from the unit and unplug immediately. Make sure the unit remains securely anchored. Do not reinflate unit until adverse weather conditions cease. When conditions permit, inflate unit and allow it to dry before using again. Never allow playing on a wet unit.

If the **KINDAS'** inflatable becomes unplugged or losses power during the operation, the attendant should hold open the door and allow the riders to exit. There is no cause for alarm, riders should be told to remain calm and follow the attendant's instructions.

**\*\*RULES\*\***

**GENERAL RULES FOR SAFE OPERATION**

- A. **NO PLAYING AROUND UNIT. STAY 10 FEETS AWAY (I.E. BLOWERS, STICKS, ETC)** \_\_\_\_\_
- B. **NO FLIPS, NO ROUGH PLAY, OR CLIMBING ON THE NET WALLS** \_\_\_\_\_
- C. **NO SHOES OR SHARPS OBJECTS IN OR AROUND THE INFLATABLE** \_\_\_\_\_
- D. **NO FOOD, DRINKS OR GUM IN OR AROUND THE INFLATALBE (\$25.00)** \_\_\_\_\_
- E. **MUST BE SUPERVISED AT ALL TIMES** \_\_\_\_\_
- F. **CHILDREN OF THE SAME AGE GROUP MUST PLAY IN THE INFLATABLE AT THE SAME TIME... DO NOT MIX AGE GROUPS.** \_\_\_\_\_
- G. **DO NOT EXCEED THE RECOMMENDED CAPACITY** \_\_\_\_\_
- H. **NO TOYS, EYEGASSES, WET KIDS OR JEWELRY** \_\_\_\_\_
- I. **NO SILLY STRING IN OR AROUND THE INFLATABLE** \_\_\_\_\_
- J. **NO BALLONS, STRINGS, SIGNS, ETC ATTACHED TO UNIT (\$10.00)** \_\_\_\_\_
- K. **NO PAINTED FACES, MAKE-UP THAT WILL STICK TO UNIT (\$25.00)** \_\_\_\_\_
- L. **WHO WILL SUPERVISE UNIT? NAME(S)** \_\_\_\_\_

*The inflatable will be issued clean and will be returned in the same conditions. Before and after activity there will be an inspection for cleanness and no destruction of property. There will be a charge of \$50.00 for the cleaning of the inflatable and Lessee understand that he or she will be responsible for any repair damage.*

*The Inflatable will be clean 10 minutes prior to pick up and ready for inspection.* \_\_\_\_\_

*Initials*

If the **KINDAS'** Inflatable is not used properly accordingly with the operating instructions, **KINDAS** reserves the rights to take the inflatable down and take it away. \_\_\_\_\_

The undersigned understand the procedures and acknowledges the proper use of the **KINDAS'** Inflatable.

\_\_\_\_\_  
LESSEE

\_\_\_\_\_  
DATE